



JINTEX

Sewing Machine Spare Parts

Juki MB-372 (10 pages)

Sewing Machine Part Book

10 pages



B4420-373-000

Cushion



B1234-372-OAO

Loop Positioning Finger
Cam



B1237-373-000

Yoke Slide



B2038-372-000

Thread Guide No.2



B2406-372-OAO

Moving Knife Asm.



B2040-373-000

Thread Guide



B2014-372-000

Tension Disc Pin No.1



B3112-372-000

Needle Bar Thread Guide



B1207-372-000

Retaining Washer



B2715-377-000

Thread Guide



B2025-372-OAO

Thread Pull-Off Lever Asm.



B3109-372-OAO

Thread Tension No.3 Asm.



B2009-372-000

Tension Releasing Lever



B2414-373-000

Gauge



B4408-372-000

Connecting Link



B1242-372-000

Needle Guard



B1237-372-000

Yoke Slide



B1235-373-000

Yoke Slide Insert



B1236-373-000

Positioning Finger Yoke
Slide



B2529-372-000

Feed Plate, Small Button



B2529-372-COO

Feed Plate, Big Button



B2529-373-000

Feed Plate, Small Button



B2529-373-COO

Feed Plate, Big Button



B1241-373-000

Throat Plate



B1241-372-000

Throat Plate



B1240-372-000

Spacer Plate



B1118-372-000

Looper Cover



B3109-377-OAO

Thread Tension No.3 Asm.



B2039-373-000

Thread Guide No.1



B1421-372-000

Needle Bar Guard



B2565-372-000

Stopper



B2515-372-000

Lengthwise Feed Adjusting



B2548-372-000

Button Clamp Stop Lever



B3101-372-OAO

Front Cover Asm.



B2502-372-000

Cam Shaft Bushing,Right



B2503-372-000

Cam Shaft Bushing,Left



B2005-373-000

Nipper Bar Bearing Block



B2001-372-OAO

Nipper Bar Actuating Lever



B1202-372-000

Needle Driving Pulley



B1204-372-000

Pulley Insert



B4416-373-AAO

Button Clamp Lifting Rod
Asm.




B2020-372-000

Release Pin



B2031-372-OAO

Thread Nipper Assembly



B2526-372-000

Crosswise Feed Indicator
Pin



B2524-372-000

Indicator Pin Bearing Block



B2525-373-NOO

Crosswise Feed Indicator



B2525-372-000

Corsswise Feed Indicator



B2015-372-OAO

Tension Post No.1 Asm.

			
B2019-372-OAO Tension Post No.2 Asm.	B1211-372-000 Stop Motion Disc Pawl (A)	B1212-372-000 Stop Motion Disc Pawl	B4415-372-000 Lifting Lever Stopper Plate
			
B1215-372-BOO Thrust Bearing	B2010-372-000 Nipper Bar Block, Rear	B2011-372-000 Nipper Bar Block	B2626-372-000 Spring
			
B1205-372-000 Spring	B2616-372-000 Spring	B2008-372-000 Nipper Bar Spring	B4419-372-000 Lifting Lever Spring



B2609-372-000

Stop Motion Lever Spring



B2560-372-000

Button Clamp Stop Pin




B1213-372-000

Screw




B1230-372-OAO

Loop Positioning Finger



B1402-372-000

Needle Bar Bushing, Upper



B1403-372-000

Needle Bar Bushing



B2410-373-000

Counter Knife



B1239-372-000

Looper



B3113-372-000

Needle Bar Clamp



B1406-372-000

Needle Bar Bearing Block



B3127-372-000

Nipper Releasing Stud



B1407-372-000

Bushing



B1408-372-000

Button Clamp Lifting Lever



B2604-372-000

Stop Motion Plunger



B1216-372-000

Looper Shaft Bushing, Rear



B1222-372-000

Looper Shaft Bushing, Rear

Shaft



B1227-372-000

Looper Shaft Bushing, Front



B4406-372-OAO

Lifting Link Lever Asm.



B4410-372-OAO

Slide Guide Asm.



B2630-372-000

Stitch Adjusting Gear



B2511-372-OAO

Lengthwise Feed Lever
Asm.



B2510-372-000

Crosswise Feed Lever



B2505-372-000

Crosswise Feed Cam



B2506-372-000

Lengthwise Feed Cam



B2505-373-000

Crosswise Feed Cam



B2506-373-000

Lengthwise Feed Cam



D2506-373-000

Lengthwise Feed Cam



D2506-373-LOO

Lengthwise Feed Cam



B2639-372-OAO

Friction Plate Holder Asm.



B4405-372-OAO

Eccentric Cam Asm.



B2635-372-000

Speed Slowing Friction
Wheel



B2629-372-000

Stitch Adjusting Gear



B1234-372-OAO

Looper Positioning Finger
Cam Asm.



B1221-372-OAO

Driven Worm Asm.



B1220-372-OAO

Cam Shaft Driven Gear
Asm.



B1228-372-OAO

Looper Positioning Finger
Cam



B1208-372-000

Stop Motion Disc Ass'y



B1210-372-OAO

Stop Motion Disc Ass'y



B2403-373-000

Thread Trimming
Connecting



B2404-373-000

Thread Trimming
Connecting



B2401-373-000

Thread Trimming Link



B2402-373-000A

Thread Trimming Lever



B2611-372-000

Stop Pressure Applying
Lever



B2636-372-000

Speed Slowing Lever



B2642-372-000

Stitch Selecting Lever



B2614-372-OAO

Stop Motion Trip Lever Asm.



B2528-372-000

Crosswise Feed Graduated
Plate



B2563-372-000

Lengthwise Feed Graduated
Plate



B2564-372-000

Lengthwise Feed Graduated
Plate



B1632-180-000

Feed Adjusting Joint



B1412-372-OAO

Ball Joint Upper Asm.



B1416-372-OAO

Ball Joint, Eccentric Asm.



B2558-372-000

Button Holder Spring, Right



B2556-372-000

Button Holder Spring, Left



B2028-372-OAO

Nipper Block Asm.



B2638-372-000

Rotating Stud



B2523-372-000

Hinged Screw



B2508-372-000

Feed Cam Roller Stud



B2521-372-000

Stud



B2036-372-000

Nipper Spring Hook Screw



B2603-372-000

Set Screw



NS-6150430-SP

Nut 15/64-28



B8210-372-OAO

Button Tray Asm.



B1125-372-OOA

Side Cover,Left



B1126-372-OOA


Side Cover,Right



B4401-372-OAO

Button Clamp Forked Rod

Asm.



B2410-372-000

Button Clamp Work Support Shank Button Adapter (B)
Plate



B2419-372-BOO



B2409-372-000

Button Clamp Feed Plate



B2440-372-OAO

Button Necking Attachment
Asm.



B2552-372-000

Button Clamp Slide



B2547-372-000

Jaw Lever Holder



B2547-372-OCO

Button Clamp Jaw Lever
Holder Asm.



B2401-372-OBO

Shank Button Clamp
Completely



B2547-372-OBO

Flat Button Clamp Ass'y



B1401-372-000

Needle Bar

			
B1414-372-000	B2605-372-000	B2601-372-000	B1201-373-000
Needle Bar Lever	Stop-Motion Plunger Rod	Stop Motion Shaft	Needle Driving Pulley Shaft

Connecting

Needle Bar Lever

Connecting

			
B2004-372-000	B1219-372-000	B2522-373-000A	B4411-373-000
Nipper Bar	Looper Shaft	Feed Plate	Button Clamp Lifting Link
			
B4412-373-000	B1409-372-000B	B1424-372-OAO	
Button Clammpp Lifting Lever	Needle Bar Rocking Pipe	Crank Rod Asm.	