



JINTEX

Sewing Machine Spare Parts

Pegasus W500 (10 pages)

Sewing Machine Part Book

10 pages



192120

Pipe



250257A

Eye Guard Asm.



252502-91

Diff. Feed Bar



252536

Spring



253004

Presser Bar




253508A

Thread Guide



253515

Thread Guide



253517

Spring




253545

Holder



253547

Thread Guide



253548

Thread Guide



255510

Lower Knife Clamp



257015B32

Throat Plate 232



257015B40

Throat Plate 240



257018B56

Throat Plate 356



257029B32

Throat Plate 232



257050B40

Throat Plate 240



257095B64

Throat Plate 364



257097B56

Throat Plate 356



257206-16F

Main Feed Dog



257214-16F

Main Feed Dog



257220-16F

Main Feed Dog



257260-16F

Diff. Feed Dog



257266-16F

Diff. Feed Dog



257301A56

Presser Foot 356



257317A32

Presser Foot 232



257468-56

Presser Foot 356



257472-56

Presser Foot 356



257501-56

Needle Clamp 356



257517-32

Needle clamp 232



350024

Lower Fixed Knife




350215

Flat Spring



350218

Top Carbide Moving Knife



350228

Spring



253534

Thread Guide (Left)



256551-91S

Rear Puller Assembly



206233

Oil Filter



257518-56

Needle Clamp 356



257553

Front Needle Guard



257565

Spreader



206125

Needle Bearing



179107-05

Oil Sight Window



206133

Oil Shield



240226

Plug



253507

Thread Guide



253533

Thread Guide (Right)



210353

Left Looper Thread Guide



253511

Thread Guide



253615

Thread Guide



253506

Thread Take-Up



250051

Flat Spring



206023

Flat Spring



253010

Spring



206439

Aux. Plate/Front Cover



252508A

Thread Guide



253505A

Thread Take-Up



252507

Guide/Left



253514

Thread Guide



254010A91

Tension Nut Ass'y (H)



253584B/ASM

Thread Guide Ass'y



253516/ASM

Thread Tension Bracket

253548/ASM

Thread Guide Complete

206157

Link

253011

Link

Ass'y



250023-UD

Thread Take-Up Cover

252509

Cover

250021-UD

Needle Bar Cover

253614

Thread Guide



255515

Chip Guard

252526

Pin

252538

Scale Plate

201914

Tape Binder Bracket



206059A

206060

253545/234521

252521

			
252522 Regulator	250050-SD Front Cover (Small)	252508 Guide/Lower	253005-91 Guide
			
206148 Bell Crank (Lower)	252519 Block	201074A Guide	206563 Guide Block
			
206053 Pin	179399-05 Screw Pin	251518 Shaft	254504 Screw Pin
			
240114A Spring	306500 Clutch Roller	256012 Clutch	253608-91 Thread Take-Up

Spring



silicone Reservoir



silicon



Thread Guide



252504

Guide/Right

252000-92

Eccentric Ass'y

253544

Thread Guide

207065-9U

Silicone oil Reservoir Ass'y



255015

Silicone oil Reservoir/Lower Oil Guard

255006

206062

Guide Block/Needle Bar

255509

Lower Knife Holder

			
255507-91 Upper Knife Lever Ass'y	254508 Crank Shaft	206061 Needle Bar Clamp	206139 Presser Bar Clamp
			
252532 Guide/Block	254516-92 Spreader Holder Lever "F"	256039 Lace Guide	254506B Crank
			
206052 Needle Bar Drive Link	206564 Diff. Feed Link	253504-92 Lever Ass'y	254503-92 Crank
			
255019 Worm Wheel	250543A91 Bushing	306093 Crank	252009-92 Connection Ass'y



254511
Connection

255501-92
Connection Ass'y

252008-92
Crank Ass'y

253501A92
Crank Ass'y



251519-92
Lever Ass'y

252533-92
Lever

252007-92
Looper Holder Ass'y

206562
Link/Main Feed



252527-91
Crank

250016-AUD
Arm Cover Left

252002
Crank

250511-91
Gear/Lower



250523AUD
Hand Wheel

255040-91
Pump Ass'y

252500-91
Main Feed Bar

252502-91
Diff. Feed Bar

			
253000-91/2530031 Adjusting Bar W/Nut	254000-91 Lever	250071-91 Slide Plate	254023E9T Tension Control Mechanism (3-N)
			
250022-UB Pulley Cover	250150-PD Arm Cover Top	250032-SD Front Cover Ass'y	253611/ASM Thread Guide Ass'y