



JINTEX


Sewing Machine Spare Parts

Siruba C007J UT

Sewing Machine Part Book

28 pages

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.1/16




FOR C007J/C007JD/C858J/C858JD

★ 适用于UTP/CR/CX, UTQ/CR/CX, UTR/CR/CX, UTS/CR/CX车型

10/12/19

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.2/16



FOR C007J/C007JD/C858J/C858JD

FOR H牌馬達
FOR P牌馬達

10/07/01

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.3/16


A

B

C


D

E




USE FOR C007J

MJ37-A



USE FOR C007JD


MJ137-E




FOR C007JD/C858JD/C007J/C858J

10/11/03


C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.4/16




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.5/16



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.6/16



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.7/16




FOR C007JD/C858JD


FOR H牌馬達 (HVP-70)
FOR P牌馬達

10/07/01

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.8/16



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.9/16




FOR C007JD/C858JD

FOR H牌馬達 (HVP-70)
FOR P牌馬達


10/07/01

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.10/16

A
B
C
D
E




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.11/16



C007JD PARTS LIST FOR UTQ-J GROUP P.12/16

A
B
C
D
E

FOR LEFT SIDE




A

B


C

D


E



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.14/16



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.15/16




FOR F007JD/C007JD/F858JD/C858JD


FOR H牌馬達 (HVP-70)

10/07/01

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.16/16



C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.1/11




FOR C007J/C007JD/ C858J/C858JD

★ 适用于UTP/CR/CX, UTQ/CR/CX, UTR/CR/CX, UTS/CR/CX車型

10/12/19

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.2/11



1 FOR C007J/C007JD/C858J/C858JD

2 FOR H牌馬達
3 FOR P牌馬達

10/07/01


C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.3/11

FOR UTR/WP/UTX


FOR UTS/UTY

UT776/WP19

A



UT218J



TO WIPER

UT226D
WP22(WP)

*SM630

*CP112

UT534

TO UNDER
TRIMMER

B

C

TO MAIN
POWER

TXXXXX

UT103E

TO SAFETY S.W

TO SYNCHRONIZER


D

T999


TO PRESSER FOOT

UT230-E
FOR CL USE

E



UT810-A1



FOR C007JD/C858JD/S007KD

*USE FOR UTR

FOR H牌馬達 (HVP-20)

10/11/24

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.3/8

FOR UTR/WP/UTX

FOR UTS/UTY

UT763 /WP19

UT218J

UT226D
UT226P
WP22(WP)

TO WIPER

*SM630

*CP112



UT534

TO UNDER TRIMMER

TO PRESSER FOOT

UT230-E
FOR CL USE

UT810-A1
UT810P-A



FOR C007JD/C858JD/S007KD

*USE FOR UTR

FOR H牌馬達 (HVP-70)

FOR P牌馬達

10/11/24

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.4/11

FOR UTR/WP/UTX

FOR UTS/UTY

UT776 /WP19

UT218J

UT226D

UT226P

WP22(WP)

TO WIPER

*SM630

*CP112

UT534



TO UNDER TRIMMER

TO PRESSER FOOT

UT230-E
FOR CL USE

UT810-A1

UT810P-A



FOR C007JD/C858JD/S007KD

*USE FOR UTR

FOR H牌馬達 (HVP-70)

FOR P牌馬達

10/11/24

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.5/11


A

B


C

D


E



USE FOR C007J



USE FOR C007JD



1

2

3

4


5

FOR H牌馬達

*USE FOR C007JD/C858JD

10/12/19

C007JDPARTS LIST FOR UTR-J(UTS-J) GROUP P.6/11



C007JD PARTS LIST FOR UTS—J GROUP P.7/11


A

B


C

D

E



UTS系列



FOR C007J/C007JD/F007J/F007JD/C858J/C858JD/F858J/F858JD

10/07/01

C007JD PARTS LIST FOR UTR-J GROUP P.8/11


A

B

C

D

E



FOR C007J/C007JD/ C858J/C858JD

10/12/19

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.9/11


A

B

C

D

E




1 FOR F007JD/C007JD/F858JD/C858JD

2 3 4 5
FOR H牌馬達 (HVP-20)

10/12/19

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.10/11




1 FOR F007JD/C007JD/F858JD/C858JD

2 3 4 5 FOR H牌馬達 (HVP-70)

10/12/19

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.11/11



1 FOR F007JD/C007JD/F858JD/C858JD

2 FOR P牌馬達

10/12/19